


# Entryphone<sup>®</sup>

## 900 Video Door Telephone System



**Automatic Operation:** In normal operation, the monitor will be activated and stay on for about 90 seconds by a caller pressing the call button on the entrance panel.

**View and/or Speak:** The occupant can view the caller and, if desired, can conduct a conversation over the system in the normal way.

**Remote Door Release:** To admit the caller, the occupant can release the door by pressing either the button marked ⊖ on the monitor or the the button marked 🗝 on the telephone.

**Manual Control:** The occupant can, at any time switch on the monitor and door camera simply by pressing the Ⓜ button on the monitor or turn off the monitor before the auto time out by pressing the button marked ⊖.