


Entryphone® 516V user instructions

Note. Some functions may not be available on your system.





The Entryphone 516V is a wall-mounted, full duplex, loudspeaking, colour video telephone. The video screen turns on automatically when the telephone is called and the lamp above the on/off touch switch will flash. If you want to speak to the caller, press the on/off touch switch and this will enable the speech connection.


If you wish to admit a visitor, press the door release 1 button. Note: the release button will only operate when the screen is on.


To end the call press the on/off switch. If you don't answer or don't end a call the telephone will turn itself off either a short time after the door has been released or after about ninety seconds of operation.

Other function switches (if enabled).

 **Do not disturb:** Press this to mute the phone; the LED above the symbol will illuminate to indicate the phone is muted and no calls will be received; press again to cancel.

 **Camera Switch:** For systems with a second camera fitted press this to toggle between the cameras or lock the view to one camera.

 **2nd lock release:** Some systems feature additional door or gate control and this switch may be used for remote operation of this second device

 **Porter call.** If your system features a porter/reception facility pressing this will call this service.

Ring Volume: On the top right of the telephone there is a ring volume adjustment that can be turned using a small screwdriver. Turn clock-wise to increase the volume.