
## Entryphone<sup>®</sup> 900 Video Door Telephone System



Automatic Operation: In normal operation, the monitor will be activated and stay on for about 90 seconds by a caller pressing the call button on the entrance panel.

View and/or Speak: The occupant can view the caller and, if desired, can conduct a conversation over the system in the normal way.

Remote Door Release: To admit the caller, the occupant can release the door by pressing either the button marked on the monitor or the the button marked  $\S$  on the telephone.

...rol: The occupan
...r and door camera simple the monitor or turn off the monitor of the monit Manual Control: The occupant can, at any time switch on the monitor and door camera simply by pressing the ① button on the monitor or turn off the monitor before the auto time out by