


To adjust volume
change gap be-
tween flapper and
bolt head

BZ81 Replacement Buzzer for 59## type telephones



At manufacture the buzzer connections are soldered to terminals A and B on the rear of the sub chassis. When replacing either re-solder or connect wires via screw terminals on the front of the sub chassis.

The Entryphone Co Ltd 23 Granville Road London SW18 5SD
Tel 020 8870 8635 Fax 020 8874 0066