



Connection Functions

At Terminal	Function
D/U D	Speech from door
D/U E	Speech to door
PSU 12	12v AC for ringing & lock
PSU 0	12v AC for ringing & lock
PSU +	12v DC for speech & lamps
PSU -	12v DC for speech & lamps
TEL A2	Ringer Warble
TEL A1	Ringer buzzer (if fitted)
TEL L	Speech from door
TEL P	Speech to door
TEL 1-10	Intercom buttons
TEL B	Common for ringers
TEL F	Common for speech
TEL G	Common for buttons

Plan 1 Provides Ringing, Communication and Door Release functions. Notes Insert LINKS everywhere shown ●●. Ringer Warble volume, all phones have a spindle at the top left corner. Speech volume is adjustable on the back of the entrance panel. Speaker and Microphone have separate controls.	Title : WDA_1_3_201_T	
	Date : August 2017	Drawn by : TH
Entryphone Co. Ltd. 23 Granville Road, London, SW18 5SD U.K. T:020 8870 8735 www.entryphone.co.uk		Application : Plan 1/3 with Trade Button