



Connection Functions

| At | Terminal | Function |
|-------|----------|-----------------------------|
| D/U | D | Speech from door |
| D/U | E | Speech to door |
| PSU | 12 | 12v AC for ringing & lock |
| PSU | 0 | 12v AC for ringing & lock |
| PSU | + | 12v DC for speech & lamps |
| PSU | - | 12v DC for speech & lamps |
| TEL | A2 | Ringer Warble |
| TEL | A1 | Ringer buzzer (if fitted) |
| TEL | L | Speech from door |
| TEL | P | Speech to door |
| TEL | 1-10 | Buttons |
| TEL | B | Common for ringers |
| TEL | F | Common for speech |
| TEL | G | Common for buttons |
| IC7RU | CBP | Common button feed |
| IC7RU | N/O | Lock relay 'open' contact |
| IC7RU | N/C | Lock relay 'closed' contact |
| IC7RU | Com | Lock relay common contact |