



**Connection Functions**

At Terminal	Function
PSU 12	12v AC for ringing
PSU 0	12v AC for ringing
PSU +	12v DC for speech
PSU -	12v DC for speech
TEL A2	Ringer Warble
TEL A1	Ringer buzzer (if fitted)
TEL L	Speech incoming
TEL P	Speech outgoing
TEL 1-4	Intercom buttons
TEL B	Common for ringers
TEL F	Common for speech
TEL G	Common for buttons

Plan B Provides internal intercom between Master and Slave phones, limited to 10 buttons on master phone.  
 Notes Insert LINKS everywhere shown ●—●. Ringer Warble volume, all phones have a spindle at the top left corner.  
 Intercom Phones have twin ringers, a Warble and Buzzer, choose preference.

Title : WDA\_B\_4\_204P

Date : August 2017 Drawn by : TH